





Subtitles on the Program

If unwanted subtitles appear in the TV programs, click the "Menu" key on the remote and then click on System Setting and Language Setting. Next, press OK and then change the Subtitle Language to Disable.



Click on the System Setting



Click on the Language Setting



Click down to Subtitle Language and change the setting to disable

Guide kindly provided by Vince Middeldorp